GF 230-DAB

O dB Mobile GlassFix® Antenna for the DAB Band

DESCRIPTION

- Half-wave, 0 dB mobile antenna for the DAB band using the GlassFix® mounting principle.
- Mounting on car window glass no holes required.
- Double-adhesion procedure ensures fast and reliable fixing.
- Internal matching unit feeds external antenna through window glass.
- Half-wave design no ground plane required.
- High positioning gives performance equal to conventionally mounted car roof antenna.
- FME FastCabling system (cable to be ordered separately).
- Simple tuning procedure by means of tuning screw on matching unit.
- Easy removable whip for car wash.
- Swivel joint for 180° angle adjustment.
- If removal of antenna installation is necessary, a quick dismantling procedure leaves no trace of the installation.



NOTE

 $\ensuremath{\mathsf{GF}}$ antennas are not suitable for car models with windows that have heat reflective coating.

ORDERING DESIGNATIONS

TYPE	PRODUCT NO.
GF 230-DAB	130000705

SPECIFICATIONS

GF 230-DAB
½ λ mobile GlassFix® Antenna
Tunable 223240 MHz
Nom. 50 Ω
Vertical
0 dB (acc. to EIA RS-329-1)
\geq 6 MHz @ SWR \leq 1.5 \geq 10 MHz @ SWR \leq 2.0
≤ 1.3 @ f.res.
25 W
Whip: Stainless steel and black-chromed brass Mount and indoor unit: Weather- and shockproof plastics Corrosion-safe and corrosion-protected metals
FME-cable to be ordered separately
Black
Approx. 61 mm
Approx. 87 g
On car windows (52 mm x 47 mm obstruction-free mounting area required)
2.5 – 7.0 mm


FME-SYSTEM ACCESSORIES

FME-CABLES	
TYPE	LENGTH
1 m FME	1 m
2 m FME	2 m
3 m FME	3 m
4 m FME	4 m
5 m FME	5 m
6 m FME	6 m
4 m FME-white	4 m white
6 m FME-white	6 m white
12 m FME-white	12 m white
18 m FME-white	18 m white

For further information about other types of FME-cables and FME-connectors, please compare the cable and connector data sheets under accessories in our catalogue.

FME-CONNECTORS	
TYPE	CONNECTOR
FME-FME	FME-FME
FME-P	Prolongation
FME-N	N
FME-FSMA	FSMA
FME-BNC	BNC
FME-TNC	TNC
FME-UHF	UHF
FME-MUHF	Mini-UHF
FME-EMUHF	Elbow-MUHF
FME-EBNC	Elbow-BNC
FME-ETNC	Elbow-TNC
FME-SMA	SMA

ASSEMBLY DETAILS





INSTALLATION

1 BEFORE INSTALLATION

- When selecting mounting location take into consideration: positions of back view mirror, wiper blade paths and defogger wires (when mounting on rear window).
 - The driver's view should not be obstructed.
- Max. allowed curvature of the glass surface on the mounting spot is 2 mm deflection per 100 mm length.
- Environmental- and car temperature must be above 15° C at installation, and installation surfaces must be dry and clean.

2. INSTALLATIONS



 Clean both sides of the windscreen where the antenna mount and the matching unit are to be fitted and then remove the protective foil from the antenna mount.



Fit mount to screen and press firmly. Apply glue along the edge between mount and glass.



3. Apply glue to the cover.



4. Fit the cover and press down firmly. After 2 - 24 hours the whip can be fitted.



5. Remove the protective foil on the matching unit.



6. Fit matching unit by pressing it firmly into position.
Secure cable using clips provided.

3. AFTER INSTALLATION

Allow the silicone gluings to dry off 2 hours at a temperature above 15°
 C. To ensure full strength of the glue, it is recommended to keep the whip off the mount for 24 hours.

4. TUNING INSTRUCTIONS

- Insert a forward/reflection-type wattmeter between the transmitter and the antenna.
- Key the transmitter and observe the forward and the reflected power.
- Adjust the tuning screw on the matching unit until minimum returned power is obtained.

REINSTALLATION KIT

A reinstallation kit including all necessary parts for transfer of the antenna to another vehicle is available under order No. »GF-RK«.

WARNING

SAFETY PRECAUTIONS

Antennas mounted on the windscreen may cause relatively high field strengths in the passenger cabin and near the dashboard.

- 1. To prevent health hazard due to RF radiation, persons must not be closer
 - than 30 cm to the antenna whip (transmitter output power to the matching
 - unit: 20 W). (DIN 57 848).
- 2. The RF signals at the dashboard may cause interference in the car's electronic equipment such as broadcast radio, computer automatics, braking systems, electronic ignition, relays etc. Some cars are more susceptible to disturbances than others. It is the responsibility of the installer to carry out a thorough check of the proper functioning under any conditions of such circuits before finishing installation.

The enclosed silicone adhesive contains acetic acid and fungicides. Keep out of reach of children and dispose properly.



PROCOM France S.A.R.L. se réserve le droit d'améliorer les spécifications sans préavis.

01/12/11

